





- Strip the cable sheath a min of 20mm from the end of the conductors.
- Sort the pairs into the correct sequence of how they will be terminated.
- The normal scheme to use is 568B.
- Trim the conductors square and to the correct length.
- Insert the cable into the plug and ensure the conductors are fully under the pins and the jacket is under the strain relief.
- Crimp the pins with a modular crimp tool.
- Check all eight contacts are fully engaged and are slightly below the plastic channels

### Required Tools

Cable stripper  
Cutters  
RJ45 crimp tool

### EIA/TIA 568 B Colour Scheme



### EIA/TIA 568 A Colour Scheme

